

**DEPENDABLE
PRODUCT
NEWS**

TUBELITE®

DEPENDABLE

LEADERS IN ECO-EFFICIENT STOREFRONT,
CURTAINWALL AND ENTRANCE SYSTEMS

Date: **06/15/16**

Engineering Bulletin: 061601

Effective Date: Immediately

Released By: **Greg Hall**

Subject: **400SS Installation Instructions**

The 400SS installation instructions have recently been updated with the following information:

- p.15 – Updated Figure 2 to clarify the prep location for weep holes in the pressure plate.
- p.19 – Added note to Step 11 to clarify proper installation sequence of the head/sill anchors.
- p.20 – Moved Step 13 and Figure 6 to a new page for clarity.
- p.21 – (new page) Added note to Step 13 to clarify installation of the head/sill anchors and added Figure 6A to illustrate.

This is now a 30-page document, dated June 2016.